

RTA

CABINET STORE

November 16, 2024

Primary White Shaker Kitchen Cabinets Price List



Sink base

Model #	Item	Price
EW-CSF42	Primary White Shaker Corner Sink Front for 42" Space - 27" W	\$126.67
EW-SB30	Primary White Shaker Sink Base Cabinet - 30" W x 34.5" H	\$227.80
EW-SB33	Primary White Shaker Sink Base Cabinet - 33" W x 34.5" H	\$241.31
EW-SB36	Primary White Shaker Sink Base Cabinet - 36" W x 34.5" H	\$247.88
EW-SB42	Primary White Shaker Sink Base Cabinet w/ CS - 42" W x 34.5" H	\$284.38
EW-VSB36	Primary White Shaker Vanity Sink Base - 36" W x 34.5" H x 21" D	\$340.24
EW-VSB42	Primary White Shaker Vanity Sink Base - 42" W x 34.5" H x 21" D	\$376.75
EW-VSB48	Primary White Shaker Vanity Sink Base - 48" W x 34.5" H x 21" D	\$420.93

Filler

Model #	Item	Price
EW-FF396	Primary White Shaker Fluted Filler - 3" W x 96" H	\$88.35
EW-OLF330	Primary White Shaker Overlay Filler - 3" W x 30" H	\$31.03
EW-OLF336	Primary White Shaker Overlay Filler - 3" W x 36" H	\$36.14
EW-OLF342	Primary White Shaker Overlay Filler - 3" W x 42" H	\$41.61
EW-OLF630	Primary White Shaker Overlay Filler - 6" W x 30" H	\$62.44
EW-F396	Primary White Shaker Filler - 3" W x 96" H	\$48.92
EW-F696	Primary White Shaker Filler - 6" W x 96" H	\$98.20

End panel

Model #	Item	Price
EW-DWR3	Primary White Shaker Dish Washer End Panel	\$105.14
EW-BPLG4896	Primary White Shaker Back Panel (Long Grain) - 48" W x 96" H x 1/4" Thick	\$172.69
EW-OP3353	Primary White Shaker Oven Cabinet Overlay Panel - 33" W x 55" H	\$129.22
EW-TEP3096	Primary White Shaker Tall End Panel	\$185.08
EW-PSP4896	Primary White Shaker 1/2" Thick Finished Plywood Panel	\$286.95

Melina

Model #	Item	Price
EW-RCM8	Primary White Shaker Royal Crown Molding	\$130.33
EW-OCM8	Primary White Shaker Outside Corner Molding	\$23.00
EW-SHOE	Primary White Shaker Shoe Molding	\$18.62
EW-SCM8	Primary White Shaker Shaker Crown Molding	\$61.34
EW-BCM8	Primary White Shaker Large Crown Molding	\$125.23
EW-BEM8	Primary White Shaker Bottom Edge Molding (Narrow Light Rail)	\$62.44
EW-BAM8	Primary White Shaker Batten Molding	\$18.26
EW-FBM8	Primary White Shaker Furniture Base Molding	\$86.16
EW-CM8	Primary White Shaker Traditional Crown Molding	\$61.34
EW-COM8	Primary White Shaker Cove Crown Molding	\$102.59

Blind door

Model #	Item	Price
EW-BB36	Primary White Shaker Blind Base Cab for 36" to 39" Space - 30" W	\$301.55
EW-BB42	Primary White Shaker Blind Base Cab for 42" to 45" Space - 36" W	\$341.71
EW-BB48	Primary White Shaker Blind Base Cab for 48" to 51" Space - 48" W	\$376.02
EW-BW3636	Primary White Shaker Blind Wall Cabinet - 36" W x 36" H	\$241.31
EW-BW3642	Primary White Shaker Blind Wall Cabinet - 36" W x 42" H	\$303.01
EW-BW3630	Primary White Shaker Blind Wall Cabinet - 36" W x 30" H	\$221.87

Pantry

Model #	Item	Price
EW-P1884	Primary White Shaker Pantry - 18" W x 84" H	\$472.04
EW-P1890	Primary White Shaker Pantry - 18" W x 90" H	\$509.26
EW-P1896	Primary White Shaker Pantry - 18" W x 96" H	\$530.07

Oven

Model #	Item	Price
EW-OC3390	Primary White Shaker Oven Cabinet - 33" W x 90" H	\$765.54
EW-OC3396	Primary White Shaker Oven Cabinet - 33" W x 96" H	\$817.76
EW-OCD337	Primary White Shaker Oven Cabinet Drawer	\$198.24

Deep

Model #	Item	Price
EW-W361824	Primary White Shaker Deep Wall Cabinet - 36" W x 18" H x 24" D	\$211.37
EW-W362424	Primary White Shaker Deep Wall Cabinet - 36" W x 24" H x 24" D	\$245.70

Single door

Model #	Item	Price
EW-W930	Primary White Shaker Single Door Wall Cabinet - 9" W x 30" H	\$90.90
EW-W936	Primary White Shaker Single Door Wall Cabinet - 9" W x 36" H	\$102.94
EW-W942	Primary White Shaker Single Door Wall Cabinet - 9" W x 42" H	\$122.30
EW-W1230	Primary White Shaker Single Door Wall Cabinet - 12" W x 30" H	\$104.42
EW-W1236	Primary White Shaker Single Door Wall Cabinet - 12" W x 36" H	\$117.55
EW-W1242	Primary White Shaker Single Door Wall Cabinet - 12" W x 42" H	\$140.18
EW-W1530	Primary White Shaker Single Door Wall Cabinet - 15" W x 30" H	\$116.82
EW-W1536	Primary White Shaker Single Door Wall Cabinet - 15" W x 36" H	\$134.70
EW-W1542	Primary White Shaker Single Door Wall Cabinet - 15" W x 42" H	\$159.53
EW-W1830	Primary White Shaker Single Door Wall Cabinet - 18" W x 30" H	\$133.97

EW-W1836	Primary White Shaker Single Door Wall Cabinet - 18" W x 36" H	\$152.60
EW-W1842	Primary White Shaker Single Door Wall Cabinet - 18" W x 42" H	\$181.81
EW-W2130	Primary White Shaker Single Door Wall Cabinet - 21" W x 30" H	\$149.68
EW-W2136	Primary White Shaker Single Door Wall Cabinet - 21" W x 36" H	\$170.48
EW-W2142	Primary White Shaker Single Door Wall Cabinet - 21" W x 42" H	\$202.61
EW-VB15	Primary White Shaker Single Door Base Vanity - 15" W x 21" D	\$183.26
EW-VB18	Primary White Shaker Single Door Base Vanity-18"W x 34.5"H x 21"D	\$197.51
EW-B12	Primary White Shaker Single Door Standard Base Cabinet - 12" W	\$180.34
EW-B09	Primary White Shaker Single Door Full Height Base Cabinet - 9" W	\$131.05
EW-B15	Primary White Shaker Single Door Standard Base Cabinet - 15" W	\$196.76
EW-B18	Primary White Shaker Single Door Standard Base Cabinet - 18" W	\$212.12
EW-B21	Primary White Shaker Single Door Standard Base Cabinet - 21" W	\$229.26

Double door

Model #	Item	Price
EW-B24-2	Primary White Shaker Double Door Standard Base Cabinet - 24" W	\$253.35
EW-B27	Primary White Shaker Double Door Standard Base Cabinet - 27" W	\$312.86
EW-B30	Primary White Shaker Double Door Standard Base Cabinet - 30" W	\$321.63
EW-B33	Primary White Shaker Double Door Standard Base Cabinet - 33" W	\$349.36
EW-B36	Primary White Shaker Double Door Standard Base Cabinet - 36" W	\$356.67
EW-V24-2	Primary White Shaker Double Door Vanity - 24" W x 34.5" H x 21"	\$174.86
EW-V27	Primary White Shaker Double Door Vanity - 27" W x 34.5" H x 21"	\$204.08
EW-V30	Primary White Shaker Double Door Vanity - 30" W x 34.5" H x 21"	\$211.37
EW-V33	Primary White Shaker Double Door Vanity - 33" W x 34.5" H x 21"	\$232.19
EW-V36	Primary White Shaker Double Door Vanity - 36" W x 34.5" H x 21"	\$246.42
EW-W2430-2	Primary White Shaker Double Door Wall Cabinet - 24" W x 30" H	\$178.16
EW-W2436-2	Primary White Shaker Double Door Wall Cabinet - 24" W x 36" H	\$207.72
EW-W2442-2	Primary White Shaker Double Door Wall Cabinet - 24" W x 42" H	\$239.84
EW-W2730	Primary White Shaker Double Door Wall Cabinet - 27" W x 30" H	\$198.96
EW-W2736	Primary White Shaker Double Door Wall Cabinet - 27" W x 36" H	\$224.89
EW-W2742	Primary White Shaker Double Door Wall Cabinet - 27" W x 42" H	\$267.22
EW-W3012	Primary White Shaker Double Door Wall Cabinet - 30" W x 12" H	\$93.09
EW-W3015	Primary White Shaker Double Door Wall Cabinet - 30" W x 15" H	\$115.36
EW-W3018	Primary White Shaker Double Door Wall Cabinet - 30" W x 18" H	\$148.95
EW-W3024	Primary White Shaker Double Door Wall Cabinet - 30" W x 24" H	\$182.54
EW-W3030	Primary White Shaker Double Door Wall Cabinet - 30" W x 30" H	\$205.54
EW-W3036	Primary White Shaker Double Door Wall Cabinet - 30" W x 36" H	\$243.50
EW-W3042	Primary White Shaker Double Door Wall Cabinet - 30" W x 42" H	\$289.13
EW-W3315	Primary White Shaker Double Door Wall Cabinet - 33" W x 15" H	\$125.96
EW-W3330	Primary White Shaker Double Door Wall Cabinet - 33" W x 30" H	\$229.26
EW-W3336	Primary White Shaker Double Door Wall Cabinet - 33" W x 36" H	\$261.40
EW-W3342	Primary White Shaker Double Door Wall Cabinet - 33" W x 42" H	\$309.93
EW-W3612	Primary White Shaker Double Door Wall Cabinet - 36" W x 12" H	\$115.36
EW-W3615	Primary White Shaker Double Door Wall Cabinet - 36" W x 15" H	\$128.87
EW-W3618	Primary White Shaker Double Door Wall Cabinet - 36" W x 18" H	\$171.21
EW-W3630	Primary White Shaker Double Door Wall Cabinet - 36" W x 30" H	\$237.67
EW-W3636	Primary White Shaker Double Door Wall Cabinet - 36" W x 36" H	\$279.27
EW-W3642	Primary White Shaker Double Door Wall Cabinet - 36" W x 42" H	\$331.48
EW-W3918	Primary White Shaker Double Door Wall Cabinet - 39" W x 18" H	\$182.54
EW-W3924	Primary White Shaker Double Door Wall Cabinet - 39" W x 24" H	\$219.76
EW-W3624	Primary White Shaker Double Door Wall Cabinet - 36" W x 24" H	\$204.81

Model #	Item	Price
EW-LSB36	Primary White Shaker Lazy Susan Cabinet - 36" W x 24" D	\$645.26

Easy reach

Model #	Item	Price
EW-WER2430	Primary White Shaker Wall Easy Reach Cabinet - 24" W x 24" D x 30" H	\$258.48
EW-WER2436	Primary White Shaker Wall Easy Reach Cabinet - 24" W x 24" D x 36" H	\$274.47
EW-WER2442	Primary White Shaker Wall Easy Reach Cabinet - 24" W x 24" D x 42" H	\$314.30
EW-ER36	Primary White Shaker Easy Reach Base Cabinet - 36" W x 24" D	\$380.39

Drawer base

Model #	Item	Price
EW-DB12-3	Primary White Shaker Drawer Base Cabinet - 12" W	\$272.70
EW-DB15-3	Primary White Shaker Drawer Base Cabinet - 15" W	\$301.55
EW-DB18-3	Primary White Shaker Drawer Base Cabinet - 18" W	\$323.81
EW-DB21-3	Primary White Shaker Drawer Base Cabinet - 21" W	\$346.45
EW-DB24-3	Primary White Shaker Drawer Base Cabinet - 24" W	\$370.17
EW-DB30-3	Primary White Shaker Drawer Base Cabinet - 30" W	\$422.38
EW-VDB12	Primary White Shaker Vanity Drawer Base - 12" W x 34.5" H x 21"	\$267.94
EW-VDB15	Primary White Shaker Vanity Drawer Base - 15" W x 34.5" H x 21"	\$289.85
EW-VDB18	Primary White Shaker Vanity Drawer Base - 18" W x 34.5" H x 21"	\$312.14
EW-VDB21	Primary White Shaker Vanity Drawer Base - 21" W x 34.5" H x 21"	\$349.36
EW-VDB24	Primary White Shaker Vanity Drawer Base - 24" W x 34.5" H x 21"	\$386.60

Wine Rack

Model #	Item	Price
EW-WR3018	Primary White Shaker Wine Rack - 30" W x 18" H x 12" D	\$163.18

Other

Model #	Item	Price
EW-SPRAYCAN	Primary White Shaker Spray Can	\$7.30
EW-TBUNFOOT	Primary White Shaker Bunfoot	\$73.01
EW-TBUNFOOT2	Primary White Shaker Transitional Bunfoot	\$73.01
EW-TKS8	Primary White Shaker Toe Kick	\$15.70
EW-TPOSTP3	Primary White Shaker Turned Post - 3" W x 35.5" H	\$131.42
EW-TPOSTP5	Primary White Shaker Turned Post - 5" W x 35.5" H	\$200.41
EW-TUKIT	Primary White Shaker Touchup Kit	\$5.48
EW-LRM8	Primary White Shaker Traditional Light Rail	\$125.23
EW-SCRIBE	Primary White Shaker Scribe	\$19.71
EW-SHELF1296	Primary White Shaker Shelf - 96" W x 12" D	\$171.21
EW-CORSM	Primary White Shaker Basic Medium Corbel - 10.5" H	\$34.69
EW-CORT	Primary White Shaker Transitional Corbel	\$97.12
EW-CW2430	Primary White Shaker Corner Wall Cabinet - 24" W x 30" H	\$223.42
EW-CW2436	Primary White Shaker Corner Wall Cabinet - 24" W x 36" H	\$250.80
EW-CW2442	Primary White Shaker Corner Wall Cabinet - 24" W x 42" H	\$317.98
EW-CW2736	Primary White Shaker Corner Wall Cabinet - 27" W x 36" H	\$286.58
EW-CW2742	Primary White Shaker Corner Wall Cabinet - 27" W x 42" H	\$340.24
EW-BBP4842	Primary White Shaker Bead Board - 48" W x 42" H x 0.25" D	\$97.12
EW-BCE1596	Primary White Shaker Book Case End - 1.5" W x 96" H x 15" D	\$141.64

